

FAX: (255 22) 2844300, 2844302

PHONE: (255 22) 2198100 AFS: HTDQYOYO

Email: tcaa@tcaa.go.tz, ais@tcaa.go.tz

Website: www.tcaa.go.tz

TANZANIA CIVIL AVIATION AUTHORITY

Aeronautical Information Services

Nyerere /Kitunda Road Junction

UNITED REPUBLIC OF TANZANIA

Aviation House, 1st Floor,

P.O. Box 2819, DAR ES SALAAM

AIP

Supplement

03/17

01 January 2017

Document No:

TCAA/FRM/ANS/AIS-56

Title: AIP Supplement

Page 1 of 1

AERODROME (AD)

S03 Mchauru – HTXX

The aerodrome is permanently equipped with lighting systems with the following details:

A: Approach and Runway Lighting

RWY Desi	gnator	APCH LGT Type LEN/ INTST	THR LGT Colour WBAR	VASIS (MEHT) PAPI	TDZ LGT LEN	RWY Centreline LGT, Length spacing colour INST	RWY edge LGT, LEN spacing colour INST	RWY End LGT Colour WBAR	SWY LGT LEN (M) colour	Remark	
	1	2	3	4	5	6	7	8	9	10	
	17	NIL	Green	APAPI Left/ 3-4°	NIL	NIL	White 60 M	Red	NIL	RWY End LGT 5 M	
	35	NIL	Green	APAPI Left/ 3-4°	NIL	NIL	White 60 M	Red	NIL	outside the edges	

B: Other Lighting

TWY edge and Centreline lights	Edge blue all TWY Centre line NIL			
Flood lights	Apron			

C: Due to high ground in the vicinity of approach runway 35, night time approach and landing should be made for runway 17 and take off runway 35 only.

Pilots shall fly en-route at not less than 7000 feet AMSL. Further descend only if they have established visual contact with the runway lights, to join left base at not less than 6000 feet AMSL and thereafter join final approach runway 17 at 5 NM not less than 5500 feet AMSL. Further descend on APAPI guidance at 5% glide slope. Pilots should note presence of high ground at 2.5 NM reaching 4300 feet AMSL and should avoid flying low on the APAPI guidance.

D: The lights can be switched on by pilot by clicking the RTF transmitter three times. Initial activation of aerodrome ground lights is on high brilliancy. The brilliancy of the aerodrome ground lights may be changed by the pilot by clicking the RTF transmitter five times to obtain medium brilliancy and seven times to obtain low brilliancy.

		ocument	

Document No:	Title: AIP Supplement	Page 2 of 2
TCAA/FRM/ANS/AIS-16		

E: In case aerodrome ground lights does not come on, pilots should advise Mchauru Information on 131.4 MHz for manual activation.

F: Any operator wishing to operate at the Mchauru Aerodrome must obtain a permission from the aerodrome operator 24 hours before Aircraft operations by using the following contact:

E – mail address: Aviation.Geita@geitagold.com

Telephone Number: - 255 28 2520500 ext: 1856/1858/1711

For other information about Mchauru aerodrome please refer AIP AD 1.3 – 12.

(Cancel AIP SUP 08/16)